

*jura*®



## Instructions for use for IMPRESSA A9 One Touch



The Instructions for Use has been awarded the seal of approval by the independent German Technical Inspection Agency, TÜV SÜD, due to its easy-to-understand style, its thoroughness and coverage of safety aspects.

de

en

fr

it

nl

es

pt

ru

## Your IMPRESSA A9 One Touch

<b>Control elements</b>	<b>36</b>
<b>Important information</b>	<b>38</b>
Proper use .....	38
For your safety .....	38
<b>1 Preparing and using for the first time</b>	<b>40</b>
JURA on the Internet .....	40
Touchscreen display .....	40
Setting up the machine .....	41
Filling the bean container .....	41
First-time use.....	41
First-time use with filter cartridge activation .....	41
First-time use without filter cartridge activation .....	42
Determining the water hardness .....	43
Connecting milk.....	43
Filling the water tank .....	43
<b>2 Preparation</b>	<b>44</b>
Ways of preparing a beverage.....	44
Ristretto, espresso and coffee .....	44
2 ristretti, 2 espressi and 2 coffees.....	44
Latte macchiato and Cappuccino .....	45
Latte macchiato doppio and Cappuccino doppio .....	45
Permanently setting the amount of water for the cup size.....	45
Ground coffee.....	46
Adjusting the grinder .....	46
Hot water.....	47
<b>3 Daily operation</b>	<b>47</b>
Switching on the machine .....	47
Daily maintenance.....	48
Regular maintenance .....	48
Switching off the machine .....	48
<b>4 Permanent settings in programming mode</b>	<b>49</b>
Replacing products on the start screen.....	49
Deactivating the start screen .....	49
Setting the water hardness .....	49
Automatic switch-off.....	50
Unit for amount of water .....	50
Language.....	50

<b>5</b>	<b>Maintenance</b>	<b>50</b>
	Rinsing the machine .....	51
	Rinsing the milk system .....	51
	Cleaning the milk system.....	51
	Dismantling and rinsing the dual spout.....	52
	Inserting and activating the filter .....	53
	Changing the filter.....	54
	Cleaning the machine.....	55
	Descaling the machine .....	56
	Cleaning the bean container .....	57
	Descaling the water tank.....	57
<b>6</b>	<b>Display messages</b>	<b>58</b>
<b>7</b>	<b>Troubleshooting</b>	<b>59</b>
<b>8</b>	<b>Transport and environmentally friendly disposal</b>	<b>60</b>
	Transport / Emptying the system .....	60
	Disposal .....	60
<b>9</b>	<b>Technical data</b>	<b>60</b>
<b>10</b>	<b>Index</b>	<b>61</b>
<b>11</b>	<b>JURA contact details / Legal information</b>	<b>64</b>

## Symbol description

### Warnings

 <b>WARNING</b>	Always take note of any information marked with the words <b>CAUTION</b> or <b>WARNING</b>
 <b>CAUTION</b>	and a warning sign. The signal word <b>WARNING</b> draws your attention to potential serious injury, and the signal word <b>CAUTION</b> to potential minor injury.
<b>CAUTION</b>	<b>CAUTION</b> draws your attention to potential damage to the machine.

### Symbols used

	<b>Prompt to take action.</b> This symbol means that you are being prompted to perform some action.
	<b>Information</b> and tips to make it even easier to use your IMPRESSA.
'Espresso'	<b>Display</b>


Control elements

# Control elements



- 1 Water tank
- 2 Mains cable (back of the machine)
- 3 Milk pipe
- 4 Coffee grounds container
- 5 Drip tray

- 6 Bean container with aroma preservation cover
- 7 Hot-water spout
- 8 Height-adjustable dual spout
- 9 Cup grille



- 1 Cover for powder chute for ground coffee
- 2 Powder chute for ground coffee (removable)
- 3 Touchscreen display
- 4  Menu symbol

- 5 Cover cap for grinder adjustment switch
- 6 Grinder adjustment switch
- 7  On/Off button

## Important information

### Proper use

The machine is designed and intended for private domestic use. It should only be used for coffee preparation and to heat milk and water. Use for any other purpose will be deemed improper. JURA Elektroapparate AG cannot accept any responsibility for the consequences of improper use.

Before using the machine read these instructions for use thoroughly and completely and comply with the instructions they contain. A warranty service is not applicable for damage or defects caused by non-compliance with the instructions for use. Keep these instructions for use close to the machine and pass them on to the next user.

### For your safety

Please carefully read and observe the important safety information set out below.

To avoid danger of potentially fatal electric shock:

- Never use a machine which is damaged or has a defective mains cable.

- In the event of signs of damage, for example if there is a smell of burning, unplug the machine immediately from the mains supply and contact JURA service.
- If the mains cable of this machine is damaged, it must be repaired either directly by JURA or by an authorised JURA service centre.
- Make sure that the IMPRESSA and the mains cable are not located close to hot surfaces.
- Be careful to ensure that the mains cable is not trapped and does not rub against sharp edges.
- Never open and repair the machine yourself. Do not modify the machine in any way that is not described in these instructions for use. The machine contains live parts. If opened, there is a danger of potentially fatal injury. Repairs may only be carried out by authorised JURA service centres, using original spare parts and accessories.
- To completely and safely disconnect the machine from the power supply, first switch off the IMPRESSA using the On/Off button. Only then should you remove the mains plug from the power socket.

There is a risk of scalds or burns on the spouts.

- Place the machine out of the reach of children.
- Do not touch any hot parts. Use the handles provided.

A defective machine is not safe and could cause injury or fire. To avoid damage and any associated risk of injury or fire:

- Never allow the mains cable to loosely hang down. The mains cable could pose a tripping hazard or become damaged.
- Protect the IMPRESSA from environmental influences such as rain, frost and direct sunlight.
- Do not immerse the IMPRESSA, mains cable or connections in water.
- Do not put the IMPRESSA or any individual parts in the dishwasher.
- Switch your IMPRESSA off at the power switch before any cleaning operation. Always wipe the IMPRESSA with a damp cloth rather than a wet one, and protect it from prolonged exposure to water splash.
- Only connect the machine to the mains voltage in accordance with the information on the rating plate. The rating plate is

located on the underside of your IMPRESSA. Further technical data is provided in these instructions for use (see Chapter 9 ‘Technical data’).

- Please only use original JURA maintenance products. Use of products that are not explicitly recommended by JURA could damage the IMPRESSA.
- Do not use any coffee beans treated with additives or caramelised coffee beans.
- Only fill the water tank with fresh, cold water.
- Switch the machine off at the power switch if you are going to be absent for a longer period of time.
- Children may not clean or service the machine unless supervised by a responsible person.
- Do not allow children to play with the machine.
- Keep children under the age of 8 away from the machine, or supervise them constantly.
- Children aged 8 and over may only operate the machine without supervision if they have been instructed in how to use it safely. Children must be able to recognise and understand the potential dangers arising from incorrect use.

People, including children, who

- do not have the physical, sensory or mental capabilities to use the machine safely or
- are inexperienced or lack knowledge in how to use the machine safely

must be supervised by a responsible person when using it, or must be instructed in how to use it correctly.

### Safety when handling the CLARIS Blue filter cartridge:

- Filter cartridges should be kept out of the reach of children.
- Store filter cartridges in a dry place in the sealed packaging.
- Protect cartridges from heat and direct sunlight.
- Do not use damaged filter cartridges.
- Do not open filter cartridges.

## 1 Preparing and using for the first time


### JURA on the Internet

Visit us on the Internet. You can download **short operating instructions** for your machine from the JURA website ([www.jura.com](http://www.jura.com)). You will also find interesting and up-to-date information on your IMPRESSA and on every aspect of coffee.


### Touchscreen display

Your IMPRESSA features an intuitive touchscreen display. There are two ways of operating the touchscreen display:

- **Touch**  
Touch the display with your finger, for example to start coffee preparation or undertake various settings in programming mode.




- **Slide**  
Move your finger from left to right (or vice versa) across the touchscreen display to select a speciality coffee in the product selector view.



## Setting up the machine

When setting up your IMPRESSA, please note the following:

- Place the IMPRESSA on a horizontal surface that is not sensitive to water.
- Choose a spot for your IMPRESSA which protects the machine against overheating. Ensure that the ventilation slots are not covered.



## Filling the bean container

The bean container has an aroma preservation cover. This will ensure that your coffee beans retain their aroma for longer.

### CAUTION

Coffee beans which have been treated with additives (e.g. sugar), ground coffee or freeze-dried coffee will damage the grinder.

- ▶ Only use untreated coffee beans to fill the bean container.
- ▶ Remove the aroma preservation cover.
- ▶ Remove any dirt or foreign objects from inside the bean container.
- ▶ Fill the bean container with coffee beans and close the aroma preservation cover.

## First-time use

When using the machine for the first time, you can choose whether you want to operate IMPRESSA **with** or **without** the CLARIS Blue filter cartridge. If the water hardness is 10 °dH or more, we recommend using the filter cartridge. If you do not know

the hardness of your water, you can find this out first (see Chapter 1 'Preparing and using for the first time – Determining the water hardness').

### **⚠ WARNING**

If the machine is operated with a defective mains cable, there is a danger of potentially fatal electric shock.

- ▶ Never use a machine which is damaged or has a defective mains cable.

**Precondition:** The bean container has been filled.

- ▶ Insert the mains plug into a power socket.
- ▶ Press the On/Off button  to switch the IMPRESSA on. The display shows the languages you can choose from.
- i** To display more languages, touch '**>**' (bottom right).
- ▶ Touch the language you want, e.g. '**English**'. '**Saved**' appears briefly on the display to confirm the setting. '**Use filter**', the box '**Active**' lights up green.

- i** Now decide whether you want to operate your IMPRESSA **with** or **without** a CLARIS Blue filter cartridge.

## First-time use with filter cartridge activation

### CAUTION

Milk, sparkling mineral water or other liquids can damage the water tank or the machine.

- ▶ Only fill the water tank with fresh, cold water.
- ▶ Touch '**Save**'. '**Saved**' appears briefly on the display. '**Insert filter**'
- ▶ Remove the water tank.

## 1 Preparing and using for the first time

- ▶ Open the filter holder and insert the filter cartridge into the water tank, exerting slight pressure.



- ▶ Close the filter holder. It will click into place audibly.

- i** After two months, the filter will cease to work. Set the date on the date plate on the filter holder in the water tank.
- ▶ Fill the water tank with fresh, cold water and reinsert the tank.
- ▶ Place a receptacle (at least 300 ml) under the hot-water spout and the dual spout.



- ▶ Touch **'Next'**.  
**'Filter is being rinsed'**, water flows out of the hot-water spout.

- i** The water may be slightly discoloured. This is not harmful to health and does not affect the taste.

Rinsing of the filter stops automatically after approximately 300 ml.

**'Welcome to JURA'**

**'System is filling'**, the system fills up with water. Water flows out of the hot-water spout and the dual spout. The operation stops automatically.

**'Machine is heating'**

**'Machine is rinsing'**, the machine rinses. The operation stops automatically. Your IMPRESSA is ready for use.

- i** The display shows the products you can prepare.

### First-time use without filter cartridge activation

#### CAUTION

Milk, sparkling mineral water or other liquids can damage the water tank or the machine.

- ▶ Only fill the water tank with fresh, cold water.

- ▶ Touch **'Inactive'**.
- ▶ Touch **'Save'**.  
**'Saved'** appears briefly on the display.  
**'Water hardness'**

- i** If you do not know the hardness of your water, you must find this out first (see Chapter 1 'Preparing and using for the first time – Determining the water hardness').

- ▶ Touch **'<'** or **'>'** to adjust the water hardness.
- ▶ Touch **'Save'**.  
**'Saved'** appears briefly on the display.  
**'Fill water tank'**
- ▶ Remove the water tank and rinse it with cold water.
- ▶ Fill the water tank with fresh, cold water and reinsert the tank.

**'Welcome to JURA'**

**'System is filling'**, the system fills up with water. Water flows out of the hot-water spout and the dual spout. The operation stops automatically.


**'Machine is rinsing'**, the machine rinses. The operation stops automatically. Your IMPRESSA is ready for use.

- i** The display shows the products you can prepare.

## Determining the water hardness

You can find out what the water hardness is by using the Aquadur® test strip supplied as standard.

- ▶ Hold the test strip briefly (for 1 second) under flowing water. Shake off the water.
- ▶ Wait for about one minute.
- ▶ You will then be able to read the degree of water hardness from the discolouration of the Aquadur® test strip and the description on the packaging.



You can now adjust the water hardness.


## Connecting milk

Your IMPRESSA creates fine, creamy, feather-light milk foam with a perfect consistency. The most important requirement for frothing milk is a milk temperature of 4–8 °C. We would therefore recommend using a milk cooler or a vacuum milk container.

- ▶ Remove the protective cover from the dual spout.



- ▶ Connect the milk pipe to the dual spout.



- ▶ Connect the other end of the milk pipe to a milk container or immerse it in a milk carton.

## Filling the water tank

Daily maintenance of the machine and hygiene when handling milk, coffee and water are key to a perfect coffee result in the cup every time. You should therefore change the water **daily**.

### CAUTION

Milk, sparkling mineral water or other liquids can damage the water tank or the machine.

- ▶ Only fill the water tank with fresh, cold water.
- ▶ Remove the water tank and rinse it with cold water.



- ▶ Fill the water tank with fresh, cold water and reinsert the tank.

## 2 Preparation

- i** You can stop preparation of a speciality coffee, speciality coffee with milk or hot water at any time. To do this, touch 'Cancel'.
- i** After a speciality coffee is selected and during grinding, the **coffee strength** is briefly displayed. You can change the coffee strength by touching the display ('<' or '>'). The next time you prepare this product, this coffee strength setting will be used.
- i** During preparation you can change the **amount of water** by touching '<' or '>'. This setting is not saved.
- i** You can follow the current status of preparation on the display.

Coffee tastes best served hot. A cold porcelain cup cools the beverage – and impairs the taste. We therefore recommend prewarming the cups. The full coffee aroma can develop only in prewarmed cups. You can purchase a JURA cup warmer from your specialised dealer.

### Ways of preparing a beverage

The IMPRESSA offers various ways of preparing a speciality coffee, milk foam or hot water:

- **Preparation using the start screen:** Simply touch the desired product on the display (start screen).  
The following products are displayed as standard on the start screen:
  - 'Cappuccino'
  - 'Latte macchiato'
  - 'Espresso'
  - 'Coffee'
- **Preparation using the product selector view:** Only some of the products you can prepare are shown on the start screen. As soon as you touch the '^' box (bottom left), more products are displayed in a **product selector view**.  
Move your finger from left to right (or vice versa) across the touchscreen display until

the desired product is displayed. Then touch 'Prepare' to start preparation.

The following additional products are shown in the product selector view:

- 'Ristretto'
- '2 ristretti'
- '2 espressi'
- '2 coffees'
- 'Hot water'
- 'Milk foam'
- 'Latte Macchiato Doppio'
- 'Cappuccino doppio'

- i** The product selector view disappears automatically after 10 seconds if no preparation is started.
- i** You have the option of replacing the four products on the start screen with your personal favourites (see Chapter 4 'Permanent settings in programming mode – Replacing products on the start screen'). Please note that the descriptions provided in the following sections always refer to the default settings.

### Ristretto, espresso and coffee

**Example:** Proceed as follows to prepare one coffee.

**Precondition:** The start screen is displayed.

- ▶ Place a cup under the coffee spout.
- ▶ Touch 'Coffee'.  
Preparation starts. The preset amount of water for coffee flows into the cup.  
Preparation stops automatically. Your IMPRESSA is once more ready for use.

### 2 ristretti, 2 espressi and 2 coffees

There are several ways of preparing **two** speciality coffees.

- When preparing a single product:
  - As soon as you start preparing a single product, '2x' is displayed in the bottom right of the display. Touch '2x' to prepare the double product.

- Using the **product selector view**:
  - In the product selector view, move your finger from left to right (or vice versa) across the touchscreen display until the required double product '**2 ristretti**', '**2 espressi**' or '**2 coffees**' is displayed. Then touch '**Prepare**'.

**Example:** Proceed as follows to prepare **two coffees** (using product selector view).

**Precondition:** The start screen is displayed.

- ▶ Place two cups under the coffee spout.
- ▶ Touch the '**^**' box (bottom left).
- ▶ Move your finger from left to right (or vice versa) across the touchscreen display until '**2 coffees**' is displayed.
- ▶ Touch '**Prepare**'.  
Coffee preparation starts.

**i** Please note that when two speciality coffees are prepared, the second is prepared immediately after the first.

The preset amount of water for coffee flows into the cups. Preparation stops automatically. Your IMPRESSA is once more ready for use.

## Latte macchiato and Cappuccino

Your IMPRESSA can prepare a latte macchiato or cappuccino at the touch of a button. There is no need to move the glass or cup.

**Example:** Proceed as follows to prepare one latte macchiato.

**Precondition:** The start screen is displayed. Milk is connected to the dual spout.

- ▶ Place a glass under the dual spout.
- ▶ Touch '**Latte macchiato**'.  
'**Latte macchiato**', the milk foam is prepared. Preparation stops automatically when the preset amount of milk is reached.

**i** There is a short interval (20 seconds) while the hot milk separates from the milk foam. This allows the typical layers of a latte macchiato to form.

Coffee preparation starts. The preset amount of water flows into the glass. Preparation stops automatically. Your IMPRESSA is once more ready for use.

To make sure the dual spout always works properly, you must rinse and clean it regularly (see Chapter 5 'Maintenance – Cleaning the milk system').

## Latte macchiato doppio and Cappuccino doppio

'Doppio' is Italian for 'double'. When you prepare a latte macchiato doppio or a cappuccino doppio, **two espressi** are dispensed one after the other directly into the hot milk foam. The result is an extra full-bodied and aromatic speciality coffee.

The amount of water and milk foam used for a latte macchiato doppio and cappuccino doppio cannot be changed. The amount of milk foam is the same as for a 'standard' latte macchiato or cappuccino. The two espressi are prepared with half the amount of water programmed for latte macchiato and cappuccino.

## Permanently setting the amount of water for the cup size

It is easy to permanently adjust the amount of water for all single products and hot water according to the cup size. Adjust the amount once as shown in the following example. Every time you prepare a drink in the future, this amount will be dispensed.

The permanent settings for adapting the amount of water to the cup size for all speciality coffees and hot water follow this model.

**Example:** Proceed as follows to **permanently** set the amount of water for one coffee.

**Precondition:** The start screen is displayed.

- ▶ Place a cup under the coffee spout.

## 2 Preparation

- ▶ Touch the 'Coffee' box for **about 2 seconds** until 'Enough coffee?' appears. Preparation starts and the coffee flows into the cup.
- ▶ Touch 'Save' as soon as there is sufficient coffee in the cup. Preparation stops. 'Saved' appears briefly on the display. The set amount of water for one coffee is permanently stored. Your IMPRESSA is once more ready for use.

- i** You can alter this setting at any time by repeating the above procedure.
- i** The amount can be permanently adjusted to the cup size for the products shown in the **product selector view** too. Move your finger across the display until the desired product is displayed. Then touch 'Prepare' for **about 2 seconds** until 'Enough coffee?' appears.


### Ground coffee

You can choose to use a second coffee variety, for example decaffeinated coffee, with the filter funnel for ground coffee.

- i** Never add more than one level measuring spoon of ground coffee.
- i** It is not possible to prepare two ristretti, two espressos or two coffees with ground coffee.
- i** Use ground coffee which is not ground too finely. Very fine coffee can block up the system so that the coffee only comes out in drips.
- i** If you did not fill the machine with a sufficient amount of ground coffee, 'Not enough ground coffee' is displayed and the IMPRESSA stops the operation.
- i** The desired speciality coffee must be prepared within approximately one minute after filling with the ground coffee. Otherwise the IMPRESSA stops the operation and is once more ready for use.

**Example:** Proceed as follows to prepare one espresso using ground coffee.

- ▶ Place an espresso cup under the coffee spout.
- ▶ Open the powder chute cover.
- ▶ 'Please add ground coffee'
- ▶ Fit the filler funnel for ground coffee on the powder chute.



- ▶ Place one level measuring spoon of ground coffee into the filler funnel.
- ▶ Close the cover of the powder chute. The start screen is displayed.
- ▶ Touch 'Espresso'. Preparation starts. The preset amount of water for espresso flows into the cup. Preparation stops automatically. Your IMPRESSA is once more ready for use.

### Adjusting the grinder

You can adjust the grinder on a continuous scale to suit the degree of roast of your coffee.

---

#### CAUTION

If you adjust the consistency of grind when the grinder is not operating, the grinder adjustment switch could be damaged.

- ▶ Only adjust the consistency of grind when the grinder is running.
- 

The consistency of grind is correct if the coffee flows regularly from the coffee spout. In addition a fine, thick crema forms.

**Example:** Proceed as follows to change the consistency of grind **during** the preparation of an espresso.

- ▶ Place a cup under the coffee spout.
  - ▶ Open the cover of the grinder adjustment switch.
  - ▶ Touch 'Espresso'.
- The coffee strength is briefly displayed. The grinder starts up.
- ▶ Turn the grinder adjustment switch to the desired position **while** the grinder is running.



The espresso is prepared and the consistency of grind is adjusted.

- ▶ Close the cover of the grinder adjustment switch.
- i** Please note that the new consistency of grind only takes effect when the second beverage is prepared.

## Hot water

### **⚠ CAUTION**

There is a danger of scalding from hot water splashes.

- ▶ Avoid direct contact with the skin.
- 
- ▶ Place a cup under the hot-water spout.



- ▶ Touch '∧' (bottom left) to go to the product selector view.
  - ▶ Move your finger from left to right (or vice versa) across the touchscreen display until 'Hot water' is displayed.
  - ▶ Touch 'Prepare'.
- 'Hot water', hot water flows into the cup. Preparation stops automatically. Your IMPRESSA is once more ready for use.

## 3 Daily operation

### Switching on the machine

Daily maintenance of the machine and hygiene when handling milk, coffee and water are key to a perfect coffee result in the cup every time. You should therefore change the water **daily**.

- ▶ Place a receptacle under the dual spout.



- ▶ Press the On/Off button  to switch the IMPRESSA on.
- 'Welcome to JURA'  
 'Machine is heating'  
 'Machine is rinsing', the system rinses itself. The operation stops automatically. Your IMPRESSA is ready for use.

### 3 Daily operation

## Daily maintenance

To ensure that you get many years of reliable service out of your IMPRESSA and to guarantee the optimum coffee quality, the machine requires daily maintenance.

- ▶ Pull out the drip tray.



- ▶ Empty the coffee grounds container and the drip tray. Rinse them both with warm water.

**i** Always empty the coffee grounds container when the machine is **switched on**. This is the only way of resetting the coffee grounds counter.

- ▶ Refit the coffee grounds container and the drip tray.
- ▶ Rinse the water tank with clean water.
- ▶ Remove the milk pipe and rinse it thoroughly under running water.
- ▶ Dismantle and rinse the dual spout (see Chapter 5 'Maintenance – Dismantling and rinsing the dual spout').
- ▶ Wipe the surface of the machine with a clean, soft, damp cloth (e.g. microfibre cloth).

## Regular maintenance

Carry out the following maintenance actions **regularly** or **as required**:

- In the interests of hygiene, we recommend changing the milk pipe on a regular basis (approximately every 3 months). Replacement pipes are available from specialised dealers (JURA original accessory set for frothers).

- Clean the inside of the water tank, e.g. with a brush. Further information about the water tank is provided in these instructions for use (see Chapter 5 'Maintenance – Descaling the water tank').
- Traces of milk and coffee may stick to the top and bottom of the cup grille. If this happens, clean the cup grille.

## Switching off the machine

When the IMPRESSA is switched off, the system is automatically rinsed if a speciality coffee has been prepared. If milk has been prepared, the milk system is rinsed too.

- ▶ Place a receptacle under the dual spout.



- ▶ Press the On/Off button . 'Machine is rinsing', 'Milk system is being rinsed', the system rinses itself. The operation stops automatically. Your IMPRESSA is switched off.

- i** Empty the water tank after switching off.
- i** When the IMPRESSA is switched off with the On/Off button, the machine does **not** consume standby energy.

## 4 Permanent settings in programming mode

Touch the Menu symbol  for about 2 seconds to view the list of maintenance programmes and switch to programming mode. The following settings can be made:

- Deactivate start screen
- Water hardness
- Units
- Automatic switch-off
- Language

You can also add your four favourite products to the start screen (see next chapter).

### Replacing products on the start screen

You have the option of replacing the four products on the start screen with your personal favourites.

**Example:** Proceed as follows to replace 'Latte macchiato' on the start screen with 'Latte Macchiato Doppio'.

**Precondition:** The start screen is displayed.

- ▶ Touch '**^**' for **about 2 seconds** until '**Replace which product?**' appears in the bottom right.
- ▶ Touch '**Latte macchiato**'.  
The product selector view is launched.
- ▶ Move your finger from left to right (or vice versa) across the touchscreen display until '**Latte Macchiato Doppio**' is displayed.
- ▶ Touch '**Save**'.  
'**Saved**' appears briefly on the display.  
'**Latte Mac. Doppio**' is displayed in the selected position on the start screen.

### Deactivating the start screen

You can deactivate the start screen so that the **product selector view** is displayed as standard.

- '**Start screen**' / '**Active**'
  - The start screen is displayed. You can go to the product selector view by touching the 'Rotary Selection' box.

- '**Start screen**' / '**Inactive**'
  - The start screen is deactivated. The **product selector view** is displayed as standard.

**Example:** Proceed as follows to deactivate the start screen.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '**>**' (bottom right) several times until the programme item '**Start screen**' is displayed.
- ▶ Touch '**Start screen**'.
- ▶ Touch '**Start screen**' / '**Active**'
- ▶ Touch '**Inactive**'.
- ▶ Touch '**Save**'.  
'**Saved**' appears briefly on the display.
- ▶ Touch the Menu symbol  to exit programming mode.  
The product selector view is displayed.

### Setting the water hardness

- i** If you are using the CLARIS Blue filter cartridge and have activated it, it is not possible to set the water hardness.

The harder the water is, the more frequently the IMPRESSA needs to be descaled. It is therefore important to set the water hardness accurately.

The water hardness can be adjusted on a continuous scale between 1 °dH and 30 °dH.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '**>**' (bottom right).
- ▶ Touch '**>**' several times until '**Water hardness**' is displayed.
- ▶ Touch '**Water hardness**'.
- ▶ Touch '**<**' or '**>**' to adjust the water hardness.
- ▶ Touch '**Save**'.  
'**Saved**' appears briefly on the display.

## 5 Maintenance

- ▶ Touch the Menu symbol  to exit programming mode.  
The start screen is displayed.

### Automatic switch-off

By instructing your IMPRESSA to automatically switch itself off, you can cut down your energy consumption. Your IMPRESSA switches off automatically after the preset time following the last action on the machine.

You can set the automatic switch-off to 15 minutes, 30 minutes or 1–15 hours.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '>' (bottom right).
- ▶ Touch '>' several times until 'Switch off after' is displayed.
- ▶ Touch 'Switch off after'.
- ▶ Touch 'Switch off after'.
- ▶ Touch '<' or '>' to change the setting.
- ▶ Touch 'Save'.
- ▶ Touch the Menu symbol  to exit programming mode.  
The start screen is displayed.

### Unit for amount of water

You can change the unit for the amount of water from 'ml' to 'oz'.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '>' (bottom right).
- ▶ Touch '>' several times until 'Units' is displayed.
- ▶ Touch 'Units'.
- ▶ Touch 'ml' or 'oz' to select the unit for the amount of water.

- ▶ Touch 'Save'.
- ▶ Touch the Menu symbol  to exit programming mode.  
The start screen is displayed.

## Language

In this programme item you can set the language used by your IMPRESSA.

**Example:** Proceed as follows to change the language from 'English' to 'Deutsch'.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '>' (bottom right).
- ▶ Touch '>' several times until 'Choose language' is displayed.
- ▶ Touch 'Choose language'.
- i** To display more languages, touch '>' (bottom right).
- ▶ Touch 'Deutsch'.
- ▶ Touch the Menu symbol  to exit programming mode.  
The start screen is displayed.

## 5 Maintenance

Your IMPRESSA has the following integrated maintenance programmes:

- Rinsing the machine ('Rinse the coffee system')
- Rinsing the milk system in the dual spout ('Rinse the milk system')
- Cleaning the milk system in the dual spout ('Clean the milk system')
- Changing the filter ('Change the filter') (only if filter is activated)
- Cleaning the machine ('Clean')
- Descaling the machine ('Descale') (only if filter is not activated)

- i** Clean or descale the machine, rinse the milk system or change the filter when you are prompted to do so.
- i** Touch the Menu symbol  for about 2 seconds to view the list of maintenance programmes. By referring to the bar you can see which maintenance programme is due. When the bar is completely filled with red, your IMPRESSA will prompt you to perform the appropriate maintenance programme.
- i** In the interests of hygiene, you should clean the milk system **daily** when you have been preparing milk.

## Rinsing the machine

You can initiate the rinse operation manually at any time.

**Precondition:** The start screen is displayed.

- ▶ Place a receptacle under the dual spout.



- ▶ Touch .
- ▶ Touch **'Rinse the coffee system'**. **'Machine is rinsing'**, water flows out of the dual spout. The rinse stops automatically. Your IMPRESSA is once more ready for use.

## Rinsing the milk system

After milk preparation, the IMPRESSA prompts you to rinse the milk system.

**Precondition:** **'Rinse the milk system'** is displayed.

- ▶ Place a receptacle under the dual spout.



- ▶ Touch **'Rinse the milk system'**. **'Milk system is being rinsed'**, water flows out of the dual spout. The rinse stops automatically. Your IMPRESSA is once more ready for use.

## Cleaning the milk system

To ensure that the milk system in the dual spout always works properly, you must clean it **daily** when you have been preparing milk.

### CAUTION

If the wrong cleaning agent is used, the machine could be damaged and/or traces could be left behind in the water.

- ▶ Use only original JURA maintenance products.

- i** JURA milk system cleaner is available from specialised dealers.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch **'Clean the milk system'**. **'Clean the milk system'**
- ▶ Touch **'Start'**.

## 5 Maintenance

- ▶ Touch **'Start'** again.  
**'Milk system cleaner'**
- ▶ Pour 250 ml of fresh water into a receptacle and add one capful of milk system cleaner.
- ▶ Immerse the milk pipe in the receptacle.
- ▶ Place another receptacle under the dual spout.



- ▶ Touch **'Next'**.  
**'Cleaning milk system'**, the dual spout and the pipe are cleaned.  
**'Fresh water'**
- ▶ Rinse the receptacle thoroughly, fill it with 250 ml of fresh water and immerse the milk pipe in the water.
- ▶ Empty the other receptacle and place it under the dual spout again.




- ▶ Touch **'Next'**.  
**'Cleaning milk system'**, the dual spout and the pipe are rinsed with fresh water. The operation stops automatically. **'Milk system cleaning complete'** appears briefly on the display. Your IMPRESSA is once more ready for use.


## Dismantling and rinsing the dual spout

The dual spout must be dismantled and rinsed **daily** if milk has been prepared to make sure it functions perfectly and also in the interests of hygiene.


- ▶ Remove the milk pipe and rinse it thoroughly under running water.




- ▶ Press the releasing devices and pull the dual spout down and off.



- ▶ Press the milk system down and take it out.




- ▶ Dismantle the milk system into its individual parts.



- ▶ Rinse all the parts under running water. If there are severely dried-on milk residues, firstly immerse the individual parts in a solution of 250 ml cold water and 1 capful of JURA milk system cleaner. Then rinse the parts thoroughly.
- ▶ Fit the air intake pipe.




- ▶ Reassemble the milk system. When doing this, note the numbering of the individual parts.



- ▶ Fit the assembled individual parts back in the dual spout and press it firmly.

- ▶ Fit the dual spout on the machine. It will click into place audibly.



## Inserting and activating the filter

Your IMPRESSA no longer has to be descaled if you are using the CLARIS Blue filter cartridge. If the water hardness is 10 °dH or more, we recommend using the filter cartridge. If you do not know the hardness of your water, you can find this out first (see Chapter 1 'Preparing and using for the first time – Determining the water hardness').

If you did not activate the filter cartridge the first time you used the machine, you can do this now as follows.

- i** Perform the 'inserting the filter' operation without any interruptions. This will ensure that your IMPRESSA always produces its best.

**Precondition:** The start screen is displayed.

- ▶ Touch the Menu symbol  for **about 2 seconds**.
- ▶ Touch '>' (bottom right) several times until the programme item '3/4' is displayed.
- ▶ Touch 'Use filter'.
- ▶ Touch 'Use filter'.
- ▶ Touch 'Active'.
- ▶ Touch 'Save'.
- ▶ 'Saved' appears briefly on the display.
- ▶ 'Insert filter'
- ▶ Remove the water tank.

## 5 Maintenance

- ▶ Open the filter holder and insert the filter cartridge into the water tank, exerting slight pressure.



- ▶ Close the filter holder. It will click into place audibly.
- i** After two months, the filter will cease to work. Set the date on the date plate on the filter holder in the water tank.
- ▶ Fill the water tank with fresh, cold water and reinsert the tank.
- ▶ Place a receptacle (at least 300 ml) under the hot-water spout.



- ▶ Touch 'Next'.  
'Filter is being rinsed', water flows out of the hot-water spout.

- i** The water may be slightly discoloured. This is not harmful to health and does not affect the taste.

Rinsing of the filter stops automatically after approximately 300 ml.

'Machine is heating'

Your IMPRESSA is once more ready for use.

## Changing the filter

- i** After 50 litres of water have flowed through, the filter will cease to work. Your IMPRESSA will automatically prompt you to change the filter.
- i** After two months, the filter will cease to work. Set the date on the date plate on the filter holder in the water tank.
- i** If the CLARIS Blue filter cartridge is not activated in programming mode, you will not be prompted to change the filter.

**Precondition:** The start screen is displayed. The box with the Maintenance symbol ☼ lights up red.

- ▶ Touch ☼.
- ▶ Touch 'Change the filter'.  
'Change the filter'

- i** If you do not want to start changing the filter just yet, press the '↑' button.

- ▶ Touch 'Start'.
- ▶ Touch 'Start' again.  
'Change the filter'
- ▶ Remove and empty the water tank.
- ▶ Open the filter holder and remove the old CLARIS Blue filter cartridge.
- ▶ Insert a **new** CLARIS filter cartridge Blue into the water tank, exerting slight pressure.



- ▶ Close the filter holder. It will click into place audibly.

- i** After two months, the filter will cease to work. Set the date on the date plate on the filter holder in the water tank.

- ▶ Fill the water tank with fresh, cold water and reinsert the tank.
- ▶ Place a receptacle (at least 300 ml) under the hot-water spout.



- ▶ Touch 'Next'.  
'Filter is being rinsed', water flows out of the hot-water spout.

**i** The water may be slightly discoloured. This is not harmful to health and does not affect the taste.

Rinsing of the filter stops automatically after approximately 300 ml.

'Machine is heating'

Your IMPRESSA is once more ready for use.

## Cleaning the machine

After 180 preparations or 80 switch-on rinses, the IMPRESSA will prompt you to clean it.

### CAUTION

If the wrong cleaning agent is used, the machine could be damaged and/or traces could be left behind in the water.

- ▶ Use only original JURA maintenance products.

- i** The cleaning programme lasts approximately 20 minutes.
- i** Do not interrupt the cleaning programme. The quality of cleaning will be impaired if you do so.
- i** JURA cleaning tablets are available from specialised dealers.

**Precondition:** The start screen is displayed. The box with the Maintenance symbol ☼ lights up red.

- ▶ Touch '☼'.
- ▶ Touch 'Clean'.  
'Clean'

**i** If you do not want to start cleaning just yet, press the '⏸' button.

- ▶ Touch 'Start'.
- ▶ Touch 'Start' again.  
'Empty grounds'
- ▶ Empty the drip tray and coffee grounds container and put them back into the machine.  
'Press the menu button'
- ▶ Touch the Menu symbol ☼.  
'Machine is being cleaned'  
The operation is interrupted, 'Add cleaning tablet'.
- ▶ Open the cover of the filler funnel for ground coffee.
- ▶ Insert a JURA cleaning tablet into the filler funnel.



- ▶ Close the cover of the filler funnel.  
'Press the menu button'
- ▶ Touch the Menu symbol ☼.  
'Machine is being cleaned'  
'Empty grounds'
- ▶ Empty the drip tray and coffee grounds container and put them back into the machine.  
Cleaning is now complete. Your IMPRESSA is once more ready for use.

## Descaling the machine

The IMPRESSA builds up deposits of limescale over time and automatically prompts you to descale it when necessary. The degree of calcification depends on the hardness of your water.

### ⚠ CAUTION

If the descaling agent comes into contact with the skin or eyes, this can cause irritation.

- ▶ Avoid contact with the skin or eyes.
- ▶ Rinse off the descaling agent with clean water. Should you get any descaling agent in your eye, see a doctor.

### CAUTION

If the wrong descaling agent is used, the machine could be damaged and/or traces could be left behind in the water.

- ▶ Use only original JURA maintenance products.

### CAUTION

If the descaling operation is interrupted, there may be damage to the machine.

- ▶ Allow the descaling programme to run to the end.

### CAUTION

If the descaling agent comes into contact with sensitive surfaces (e.g. marble), damage cannot be ruled out.

- ▶ Clean up any splashes immediately.

- i** The descaling programme lasts approximately 45 minutes.
- i** JURA descaling tablets are available from specialised dealers.
- i** If you use a CLARIS Blue filter cartridge and this is activated, you will not be prompted to descale.

**Precondition:** The start screen is displayed. The box with the Maintenance symbol  lights up red.


- ▶ Touch .
- ▶ Touch **'Descale'**.
- ▶ **'Descale'**

**i** If you do not want to start descaling just yet, press the **'L'** button.

- ▶ Touch **'Start'**.
- ▶ Touch **'Start'** again.
- ▶ **'Empty drip tray'**
- ▶ Empty the drip tray and coffee grounds container and put them back into the machine.
- ▶ **'Agent in tank'**
- ▶ Place a receptacle under the hot-water spout.



- ▶ Remove and empty the water tank.
- ▶ Completely dissolve 3 JURA descaling tablets in a receptacle holding 500 ml of water. This may take several minutes.



- ▶ Pour the solution into the empty water tank and insert it into the machine.
- ▶ **'Press the menu button'**
- ▶ Touch the Menu symbol .
- ▶ **'Machine is being descaled'**, water flows out of the hot-water nozzle repeatedly. The operation is interrupted, **'Empty drip tray'**.
- ▶ Empty the receptacle.

- ▶ Empty the drip tray and coffee grounds container and put them back into the machine.  
**'Fill water tank'**
- ▶ Place a receptacle under the dual spout and the hot-water spout.



- ▶ Remove the water tank and rinse it thoroughly.
- ▶ Fill the water tank with fresh, cold water and reinsert the tank.  
**'Press the menu button'**
- ▶ Touch the Menu symbol .  
**'Machine is being descaled'**, water flows out of the dual and hot-water spout.  
**'Machine is rinsing'**, water flows out of the dual spout.  
The operation stops automatically, **'Empty drip tray'**.
- ▶ Empty the drip tray and coffee grounds container and put them back into the machine.  
Descaling is now complete. Your IMPRESSA is once more ready for use.

**i** If the descaling operation stops unexpectedly, rinse the water tank thoroughly.

## Cleaning the bean container

Coffee beans may be covered with a slight oil film which remains on the walls of the bean container. These traces may negatively affect the coffee result. For this reason clean the bean container from time to time.

**Precondition:** **'Fill bean container'** is displayed.

- ▶ Switch the machine off with the On/Off button .
- ▶ Remove the aroma preservation cover.
- ▶ Clean the bean container with a soft, dry cloth.
- ▶ Fill the bean container with coffee beans and close the aroma preservation cover.

## Descaling the water tank

Limescale deposits may form in the water tank. To ensure correct function of the machine, descale the water tank from time to time.

- ▶ Remove the water tank.
- ▶ If you use a CLARIS Blue filter cartridge, remove this.
- ▶ Completely fill the water tank and dissolve 3 JURA descaling tablets in it.
- ▶ Leave the water tank with the descaling solution for several hours (e.g. overnight).
- ▶ Empty the water tank and rinse it thoroughly.
- ▶ If you use a CLARIS Blue filter cartridge, insert this again.
- ▶ Fill the water tank with fresh, cold water and reinsert the tank.

## 6 Display messages

Message	Cause/Result	Action
'Fill water tank'	The water tank is empty. You cannot prepare any products.	▶ Fill the water tank (see Chapter 1 'Preparing and using for the first time – Filling the water tank').
'Empty grounds'	The coffee grounds container is full. You cannot prepare any products.	▶ Empty the coffee grounds container and the drip tray (see Chapter 3 'Daily operation – Daily maintenance').
'Empty drip tray'	The drip tray is full. You cannot prepare any products.	▶ Empty the coffee grounds container and the drip tray (see Chapter 3 'Daily operation – Daily maintenance').
'Tray missing'	The drip tray and coffee grounds container are not fitted correctly or not fitted at all. You cannot prepare any products.	▶ Fit the coffee grounds container and the drip tray.
'Fill bean container'	The bean container is empty. You cannot prepare any products.	▶ Fill the bean container (see Chapter 1 'Preparing and using for the first time – Filling the bean container').
'Beancover is not fitted'	The aroma preservation cover for the bean container is not fitted or not fitted correctly.	▶ Fit the aroma preservation cover correctly.
'Rinse the milk system', the box with the Maintenance symbol ☼ lights up red.	The IMPRESSA is prompting you to rinse the milk system.	Touch the box with the Maintenance symbol ☼ to start rinsing the milk system.
The box with the Maintenance symbol ☼ lights up red.	The IMPRESSA is prompting you to perform a maintenance programme.	Touch the box with the Maintenance symbol ☼ to view the list of maintenance programmes. By referring to the bar you can see which maintenance programme is due. When the bar is completely filled with red, your IMPRESSA will prompt you to perform the appropriate maintenance programme.
'Not enough ground coffee'	There is insufficient ground coffee in the machine; the IMPRESSA stops the operation.	▶ The next time you prepare a beverage, add more ground coffee (see Chapter 2 'Preparation – Ground coffee').
'Too hot'	The system is too hot to start a maintenance programme.	Wait a few minutes until the system has cooled down.

## 7 Troubleshooting

Problem	Cause/Result	Action
Insufficient foam is produced when the milk is frothed, or milk sprays from the dual spout.	The dual spout is dirty.	<ul style="list-style-type: none"> <li>▶ Clean the milk system in the dual spout (see Chapter 5 'Maintenance – Cleaning the milk system').</li> <li>▶ Dismantle and rinse the dual spout (see Chapter 5 'Maintenance – Dismantling and rinsing the dual spout').</li> </ul>
Coffee only comes out in drips when it is being prepared.	Coffee or ground coffee has been ground too finely and is blocking the system. The same filter cartridge may have been used several times or the water hardness set incorrectly in the programming mode.	<ul style="list-style-type: none"> <li>▶ Put the grinder on a coarser setting or use coarser ground coffee (see Chapter 2 'Preparation – Adjusting the grinder').</li> <li>▶ Perform descaling (see Chapter 5 'Maintenance – Descaling the machine').</li> </ul>
Water hardness cannot be adjusted.	The CLARIS Blue filter cartridge is activated.	<ul style="list-style-type: none"> <li>▶ Deactivate the filter cartridge in programming mode.</li> </ul>
'Fill water tank' is displayed although the water tank is full.	The water tank float is trapped.	<ul style="list-style-type: none"> <li>▶ Descale the water tank (see Chapter 5 'Maintenance – Descaling the water tank').</li> </ul>
Grinder is making a very loud noise.	There are foreign objects in the grinder.	<ul style="list-style-type: none"> <li>▶ Contact customer support in your country (see Chapter 11 'JURA contact details / Legal information').</li> </ul>
'ERROR 2' or 'ERROR 5' is displayed.	If the machine was exposed to the cold for a long period of time, heating is disabled for safety reasons.	<ul style="list-style-type: none"> <li>▶ Warm the machine at room temperature.</li> </ul>
Other 'ERROR' messages are displayed.	–	<ul style="list-style-type: none"> <li>▶ Contact customer support in your country (see Chapter 11 'JURA contact details / Legal information').</li> </ul>

**i** If you were unable to solve the problem, contact customer support in your country (see Chapter 11 'JURA contact details / Legal information').

## 8 Transport and environmentally friendly disposal

### Transport / Emptying the system

In order to protect the IMPRESSA from frost during transport, the system must be emptied.

**Precondition:** The start screen is displayed.

- ▶ Touch the 'Rotary Selection' box.  
The product selector view is launched.
- ▶ Move your finger from left to right (or vice versa) across the touchscreen display until 'Hot water' is displayed.
- ▶ Touch 'Prepare'.  
'Hot water', water flows out of the hot-water spout.
- ▶ Remove and empty the water tank.  
Water will flow out of the hot-water spout until the system is empty.  
'Fill water tank'
- ▶ Switch the machine off with the On/Off button .  
Your IMPRESSA is switched off.

### Disposal

Please dispose of old machines in an environmentally neutral way.



Old machines contain valuable, recyclable materials which should be recycled. Please therefore dispose of old machines via suitable collection systems.

## 9 Technical data

Voltage	220–240 V ~, 50 Hz
Power	1450 W
Conformity mark	<b>CE</b> 
Pump pressure	static, max. 15 bar
Holding capacity of water tank (without filter)	1.1 l
Holding capacity of bean container	125 g
Holding capacity of coffee grounds container	Approx. 10 servings
Cable length	approx. 1.1 m
Weight	approx. 10.9 kg
Dimensions (W × H × D)	23.9 × 32.3 × 44.5 cm

Information for testers (repeat test in accordance with DIN VDE 0701-0702): The central grounding point (CGP) is located on the underside of the machine, on the right and at the back.

## 10 Index

### A

- Addresses 64
- Aroma preservation cover
  - Bean container with aroma preservation cover 36
- Automatic switch-off 50

### B

- Bean container
  - Bean container with aroma preservation cover 36
  - Cleaning 57
  - Filling 41
- Bus bar
  - Technical data 60
- Button
  - On/Off button 37

### C

- Cappuccino 45
- Cappuccino doppio 45
- Cappuccino frother cleaning
  - Cleaning the milk system 51
- Cappuccino frother rinsing
  - Rinsing the milk system 51
- Central grounding point 60
- CLARIS Blue filter cartridge
  - Changing 54
  - Inserting and activating the filter 53
- Cleaning
  - Bean container 57
  - Machine 55
- Coffee 44
  - 2 coffees 44
- Coffee grounds container 36
- Consistency of grind
  - Adjusting the grinder 46
  - Grinder adjustment switch 37
- Contact details 64
- Cup grille 36
- Customer support 64

### D

- Descaling
  - Machine 56
  - Water tank 57

### Display

- Touch display 37, 40
- Display messages 58
- Disposal 60
- Double product 44
- Drip tray 36
- Dual spout
  - Dismantling and cleaning 52
  - Height-adjustable dual spout 36

### E

- Emptying the system 60
- Errors
  - Troubleshooting 59
- Espresso
  - 2 espressi 44
- Espresso 44

### F

- Filling
  - Bean container 41
  - Water tank 43
- Filter
  - Changing 54
  - Inserting and activating the filter 53
- First-time use 41
  - With filter cartridge activation 41
  - Without filter cartridge activation 42

### G

- Grinder adjustment switch 37
- Ground coffee 46
  - Powder chute for ground coffee 37
- Grounding point 60

### H

- Hotline 64
- Hot water 47
- Hot-water spout 36

### I

- Instant coffee
  - Ground coffee 46
- Internet 40

### J

- JURA
  - Contact details 64
  - Internet 40

## L

- Language 50
- Latte macchiato 45
- Latte macchiato doppio 45

## M

- Machine
  - Cleaning 55
  - Descaling 56
  - Regular maintenance 48
  - Rinsing 51
  - Setting up 41
  - Switching off 48
  - Switching on 47
- Mains cable 36
- Maintenance 50
  - Daily maintenance 48
  - Regular maintenance 48
- Menu symbol 37
  - Menu symbol 37
- Messages, display 58
- Milk
  - Connecting milk 43
- Milk system
  - Cleaning 51
  - Rinsing 51

## P

- Permanently setting the water for the cup size 45
- Permanent settings in programming mode 49
- Powder chute
  - Powder chute for ground coffee 37
- Preparation 44
  - 2 coffees 44
  - 2 espressi 44
  - 2 ristretti 44
- At the touch of a button 44
- Cappuccino 45
- Cappuccino doppio 45
- Coffee 44
- Espresso 44
- Ground coffee 46
- Hot water 47
- Latte macchiato 45
- Latte macchiato doppio 45
- Ristretto 44
- Two speciality coffees 44
- Using the product selector 44

- Preparation options 44
- Problems
  - Troubleshooting 59
- Product selector view 44
- Programming mode 49
  - Automatic switch-off 50
  - Deactivating the start screen 49
  - Language 50
  - Replacing products on the start screen 49
  - Setting the water hardness 49
  - Unit for amount of water 50
- Proper use 38

## R

- Regular maintenance 48
- Rinsing
  - Machine 51
- Ristretto 44
  - 2 ristretti 44
- Rotary Selection 44

## S

- Safety 38
- Safety information 38
- Settings
  - Permanent settings in programming mode 49
- Setting up
  - Setting up the machine 41
- Short operating instructions 40
- Spout
  - Height-adjustable dual spout 36
  - Hot-water spout 36
- Switching off 48
- Switching on 47
- Switch-off
  - Automatic switch-off 50
- Symbol description 35

## T

- Technical data 60
- Tel 64
- Touchscreen display 37, 40
- Transport 60
- Troubleshooting 59
- Two products 44

## U

- Unit for amount of water 50
- Use, First-time 41

**W**

- Water hardness
  - Determining the water hardness 43
  - Setting the water hardness 49
- Water tank 36
  - Descaling 57
  - Filling 43
- Website 40

en

## 11 JURA contact details / Legal information

# 11 JURA contact details / Legal information

JURA Elektroapparate AG  
Kaffeeweltstrasse 10  
CH-4626 Niederbuchsiten  
Tel. +41 (0)62 38 98 233

@ You will find additional contact details for your country at **[www.jura.com](http://www.jura.com)**.

### Directives

The machine complies with the following directives:

- 2006/95/EC – Low Voltage Directive
- 2004/108/EC – Electromagnetic Compatibility
- 2009/125/EC – Ecodesign Directive
- 2011/65/EU – RoHS Directive

### Technical changes

We reserve the right to make technical changes. The diagrams used in these instructions for use are for illustration purposes only and do not represent the original colours of the machine. Some details of your IMPRESSA may vary.

### Feedback

Your opinion is important to us! Use the contact link at [www.jura.com](http://www.jura.com).

### Copyright

The instructions for use contain information which is protected by copyright. It is not permitted to photocopy these instructions for use or translate them into another language without the prior written consent of JURA Elektroapparate AG.